Operating and Installation Instructions for Nozzle Band Heaters:

Content:

1. **General**
2. **Technical data**
3. **Liability**
4. **Safety instructions**
5. **Installation and Commissioning**
6. **Maintenance**
7. **Repairs – spare parts**
8. **Dismantling**
9. **Storage**
10. **Disposal**

1. General

Nozzle band heaters, hereinafter referred to as heating elements, are primarily used to heat the nozzle area of injection moulding machines. In addition, they can also be used to heat all metal cylinders in industrial applications.

Deviating usages require mutual agreement and such usages should be approved and released by the manufacturer. Otherwise, neither warranty nor liability shall be assumed.

Specified load limits must not be exceeded. Compliance with the operating, maintenance and repair conditions specified by the manufacturer is also a part of the intended use.

In addition to this manual, the binding accident prevention regulations in force in the country of use and at the place of use as well as the recognised technical rules for safe and professional work must be observed.

VDE regulations:

The product is manufactured in accordance with the following standards, where applicable:

- DIN-EN 60335-1
- VDE 0700-1

The production of the heating elements is certified according to the current DIN-EN ISO - standards certified by TÜV Thüringen.

This product is electrical equipment. Read these instructions carefully before installation and commissioning. Faultless functioning and operational safety can only be guaranteed if the general safety regulations for electrical installations and the special safety and installation instructions in this manual are observed during installation.

The heating element may only be used in accordance with the following instructions. Gebr. Bach GmbH accepts no liability for damage caused by failure to observe the instructions.

2. Technical data

Depending on the application, we distinguish between two types:

Type	Operating Temperature max. in °C	Thermal load max. in W/cm²
BDS	350	5.5
BDK	550	10

NOZZLE BAND HEATERS TYPE BDS

Connection voltage:	General **230 V**; different voltages on request
Power:	See table; different wattages on request
Dimensions:	See table; different dimensions on request
Design:	Impervious to plastic with brass sheath; **for special applications or for use with PVC, with a stainless-steel sheath (BDSE)**; the implementation of a thermocouple is always possible
Electric connection:	Fixed connection cable with strain relief and kink protection; cable material: pure nickel stranded wire with a protective braid made of galvanised steel wire. **Standard length: 300 mm**; other lengths available on request

NOZZLE BAND HEATERS TYPE BDK

Connection voltage:	General **230 V**; different voltages on request
Power:	See table; different wattages on request
Dimensions:	See table; different dimensions on request
Design:	Impervious to plastic, **only available with stainless-steel sheath**; the implementation of a thermocouple is always possible
Electric connection:	Fixed connection cable with strain relief and kink protection; cable material: pure nickel stranded wire with a protective braid made of galvanised steel wire. **Standard length: 800 mm**; other lengths available on request

In principle, individual customer requirements in terms of material, dimensions and electrical parameters can be realized after consultation and clarification of all technical details.

3. Liability

Incorrect installation and incorrect selection of the temperature control can lead to defects and accidents. Any other or deviating conditions of use require the written approval of the manufacturer, otherwise neither warranty nor liability will be accepted for these and for any resulting damage. The same applies to unauthorized modifications to the product.

Our liability is limited to damage that has occurred during intended use. We are not liable for safety defects that are not yet recognizable according to the current state of the art. The contractually agreed time applies as the warranty / guarantee period.

4. Safety instructions

The heating element is not intended for use in Ex systems. When handling electrical equipment, please observe the following:

The relevant fire protection precautions must be observed. No critical conditions may occur both at the heating element and in the material to be heated (such as fire, explosion, smoke and gas

development, etc.). Installation, maintenance and servicing of the heating element are the responsibility of a qualified electrician.

The heating elements may only be operated with a suitable temperature control that prevents the maximum permissible operating temperature from being exceeded. In the event of power supply malfunctions and/or damage to the electrical equipment, the heating element must be switched off immediately. Safety devices must not be bypassed, dismantled, altered in their function or bypassed in any other way.

For all work on the heating element, the heating element must be disconnected from the power supply and secured against being switched on again. The specified operating temperature of the heating elements does not apply to the connecting cable. If necessary, the connecting cable must be adapted to the application.

Remark: **The contact protection for the electrical connection is to be ensured by the user.**

The accident prevention regulations in the user's company must be observed.

5. Installation and commissioning

The heating element may only be handled by instructed and authorized persons. The heating element may only be used in a technically perfect condition and in accordance with its intended use and in a safety-conscious and hazard-conscious manner.

During assembly, avoid deformation and excessive spreading of the heating element. Difficult mounting conditions should be taken into account at the design stage. The heating elements may only be operated with a suitable temperature control.

The following points should be noted:

- As heat is transferred from the heating elements to the object to be heated via contact heat (BDS, BDSE), the entire inner surface of the heating element must be in firm and even contact with the object to be heated.
- Holes, grooves or similar features beneath the heating element must be avoided.
- If the connection is not form-fitting, the heating element will be destroyed by overheating.
- If there are several clamping screws, these must be tightened in an alternating sequence. The clamping screws must be tightened firmly and evenly to 3 to 3.3 Nm.
- As a general rule, however, care must be taken to ensure that no mechanical damage can occur to the metal parts or the wiring.

Electrical installation:

- The electrical connection may only be carried out by an authorized electrician or by appropriately instructed specialist personnel.
- The grounding of the heating element must be ensured by an appropriate installation, if the heating element was ordered without ground connection.
- Make sure that the operating voltage is the same as the supply voltage. All connections must be made with heat-resistant cables. These must be laid in such a way that they do not come into contact with sharp-edged metal parts or heat-radiating surfaces.

The heating element may only be put into operation after complete assembly. During the initial start-up until the operating temperature is reached, the tight fit of the heating element must be checked at several intervals. If necessary, the tensioning screws must be retightened with 3 to 3.5 Nm.

6. Maintenance

Regular testing by a qualified electrician is mandatory. The period depends on the operational conditions and is to be determined and carried out by the user on his own responsibility.

7. Repairs - Spare Parts

Repairs may only be carried out by our service staff or qualified electricians. You can get spare parts on request from Gebr. Bach GmbH. Any liability on the part of Gebr. Bach GmbH is excluded for damage caused by the use of spare parts, accessories, lubricants and cleaning agents not supplied and approved by Gebr. Bach GmbH.

8. Dismantling

If the heating element is to be used again later, deformation of the heating element must be avoided. To allow easy disassembly, the clamping screws should be treated with a heat-resistant lubricant.

9. Storage

The heating element must be stored in a dry and dust-free place. If stored too moist, the insulating material used can absorb moisture and there is a risk of a short circuit.

10. Disposal

During disposal, the legal regulations in force in the country of operation and at the place of use at the time of disposal must be complied with.

GEBR. BACH GMBH
ELEKTRO-WÄRMETECHNIK

Hamburger Straße 4b
DE-99885 Ohrdruf

Phone: +49 (0) 3624 – 3073 0
Fax: +49 (0) 3624 – 3073 200
Email: mail@etb-bach.com